

Characteristics:

- long lasting
- best references
- Siemens PLC control
- Operation Siemens OP
- Easy installing and starting
- High-quality built-in components
- Top fabrication (CAD and CAM technologies)
- Competent service

Safety:

SchrumpfLift / SchrumpfTwist

The rotation of the turntable is monitored.
In case of a malfunction the process is stopped within two seconds.

Both burners are equipped with flame sensors.
If a certain temperature is not achieved immediately after the start and escaping of gas, the gas valves are switched on.

The flames do not affect the packaged good or the foil as the distance is definite.

A contact switch stops the machine, e.g. if the pallet load is shifting or packed unfavourable.

All relevant mountings for gas operation are according to official regulations of DVGW with recorded numbers e.g. tubes, valves, mountings, probes, threaded joints etc.

Switch on and off at the top and at the bottom.



www.dentz-maschinensysteme.de
info@dentz-maschinensysteme.de

Dentz Maschinensysteme GmbH

Heinkelstr. 4
D-71384 Weinstadt

Tel.: +49 (0)7151 95 66 84
Fax: +49 (0)7151 95 66 86